



PATCH KIT INSTRUCTIONS

BUCKET A

Pre Mixed patch kit. Materials are already mixed and ready to use. Add water to material and make moist for patch. You have 12-24 hours until material completely sets up.

BUCKETS MARKED B

Portland and Sand. Mix 4 parts sand and 1 part Portland. Only add enough water to make sand sticky.

- **A bonding agent can be added to increase bonding strength, but it is not required**

Questions Call:

817-332-2373 Ask for Cast Stone Department